

FIG . 1



FIG . 2

FIG . 3

03800305 060604

FIG . 4

FAULTY CROSS-BAR SWITCH	BYTE 0	BYTE 1	BYTE 2	BYTE 3	BYTE 4	BYTE 5	BYTE 6	BYTE 7
CROSS-BAR SWITCH 10	CROSS-BAR SWITCH 11	CROSS-BAR SWITCH 12	CROSS-BAR SWITCH 13	CROSS-BAR SWITCH 14	CROSS-BAR SWITCH 15	CROSS-BAR SWITCH 16	CROSS-BAR SWITCH 17	CROSS-BAR SWITCH 18
CROSS-BAR SWITCH 11	CROSS-BAR SWITCH 10	CROSS-BAR SWITCH 12	CROSS-BAR SWITCH 13	CROSS-BAR SWITCH 14	CROSS-BAR SWITCH 15	CROSS-BAR SWITCH 16	CROSS-BAR SWITCH 17	CROSS-BAR SWITCH 18
CROSS-BAR SWITCH 12	CROSS-BAR SWITCH 10	CROSS-BAR SWITCH 11	CROSS-BAR SWITCH 13	CROSS-BAR SWITCH 14	CROSS-BAR SWITCH 15	CROSS-BAR SWITCH 16	CROSS-BAR SWITCH 17	CROSS-BAR SWITCH 18
CROSS-BAR SWITCH 13	CROSS-BAR SWITCH 10	CROSS-BAR SWITCH 11	CROSS-BAR SWITCH 12	CROSS-BAR SWITCH 14	CROSS-BAR SWITCH 15	CROSS-BAR SWITCH 16	CROSS-BAR SWITCH 17	CROSS-BAR SWITCH 18
CROSS-BAR SWITCH 14	CROSS-BAR SWITCH 10	CROSS-BAR SWITCH 11	CROSS-BAR SWITCH 12	CROSS-BAR SWITCH 13	CROSS-BAR SWITCH 15	CROSS-BAR SWITCH 16	CROSS-BAR SWITCH 17	CROSS-BAR SWITCH 18
CROSS-BAR SWITCH 15	CROSS-BAR SWITCH 10	CROSS-BAR SWITCH 11	CROSS-BAR SWITCH 12	CROSS-BAR SWITCH 13	CROSS-BAR SWITCH 15	CROSS-BAR SWITCH 16	CROSS-BAR SWITCH 17	CROSS-BAR SWITCH 18
CROSS-BAR SWITCH 16	CROSS-BAR SWITCH 10	CROSS-BAR SWITCH 11	CROSS-BAR SWITCH 12	CROSS-BAR SWITCH 13	CROSS-BAR SWITCH 14	CROSS-BAR SWITCH 16	CROSS-BAR SWITCH 17	CROSS-BAR SWITCH 18
CROSS-BAR SWITCH 17	CROSS-BAR SWITCH 10	CROSS-BAR SWITCH 11	CROSS-BAR SWITCH 12	CROSS-BAR SWITCH 13	CROSS-BAR SWITCH 14	CROSS-BAR SWITCH 15	CROSS-BAR SWITCH 16	CROSS-BAR SWITCH 17
CROSS-BAR SWITCH 18	CROSS-BAR SWITCH 10	CROSS-BAR SWITCH 11	CROSS-BAR SWITCH 12	CROSS-BAR SWITCH 13	CROSS-BAR SWITCH 14	CROSS-BAR SWITCH 15	CROSS-BAR SWITCH 16	CROSS-BAR SWITCH 17
NONE FAULTY								